

SYMBOL LS2208 felprogramozása Boltadmin-hoz



Set Factory Defaults



Enable Keypad Emulation



Scan Options



<PREFIX> <DATA> <SUFFIX>



Enter



Scan Prefix



5



0



0



9



Enter Key (Carriage Return/Line Feed)